

8 Unscrew the speaker bezel slot-head screws. 9 Remove the speaker grille bezel. Note: the bezel is located with a tab at each end. Do not lever the bezel off at an angle, as that could damage the tabs. Gently pry the bezel off, a little at a time from each side, so that it comes away straight from the main housing. 10 Remove the non-functional speaker grille. 11 Unscrew the screw and the M5 nut from the radio side panel. 12 Undock the holotape-player end of the coiled cable and slide out the non-functional radio side panel, coiled cable, and the attached mechanism. 13 Remove the radio dial glass.

14 Slide out the whole vacuum tube sub-assembly. **15** Step not shown Dismantle the vacuum tube sub-assembly.



springs on to the new tube support tray and fit the vacuum tubes to the tray, over the springs. 17 Slide the tray into the new vacuum housing. 18 Slide the original back panel into the new vacuum housing. 19 Fit the vacuum grille to the front of the vacuum tube sub-assembly. IMPORTANT NOTE: for the next step, take care not to touch or damage the speaker cone. The speaker has a strong magnet, so be careful not to let any steel screws or other metal objects become attracted to the front of the speaker cone.





removal ribbon is behind the cells. **21** Slide the new vacuum tube sub-assembly back into place between the sensor and radio housings. **22** Fit the radio dial glass. **23** Carefully slide the radio into the radio housing, ensuring that the coiled cable grommet lines up with its respective recess in the underside of the radio main housing and that the M5 bolt locates through the hole in the radio module side panel.



OPERATING INSTRUCTIONS

TOGGLE SWITCH: When the radio is off - a single click powers up. When the radio is on - a single click forwards and a single click backwards scans up and down FM radio channels; a double click powers down. Long press forwards or backwards for volume up and volume down.

"TUNING" KNOB: Turning the "tuning" knob adjusts the dial pointer and "tunes" radio to one of 20 randomly selected Wasteland broadcasts.

IMPORTANT NOTE: this is a small radio with a short coiled-cable antenna, and is intended only for fun use. Radio reception will vary greatly depending on atmospheric conditions and the distance to your nearest broadcasting station. If you experience poor reception, please move the Pip-Boy to a position with a stronger radio signal.